

TRIMMER LINE INSTALLATION

Insert precut single 8" length of nylon cutting line into each opening on outside of trimmer head up to the inner ring. A minimum of 6" of line should be extended equally on each side, to insure proper balance and length.

TRIMMER LINE DIAMETER USAGE

All Curved Shaft Line Trimmers Use Line Diameter .095" To .105"
Line Trimmers Engine Size 15cc. To 24cc. Use Line Diameter .095" To .105"
Line Trimmers Engine Size 25cc. & UP Use Line Diameter .095" To .155"

**To Order Kwik Loader Original Replacement 8" Precut Line In
3lb. Bulk Pack or Consumer Pack Contact Your Dealer Or Retailer.**

WARRANTY: Limited 90 Day Warranty On Homeowner Use, 30 Days Commercial Use
Lifetime Warranty (ON Line-Locking System) From the Date Of Sale
On Parts Found To Be Defective In Material and/or Workmanship.

WARNING !

Always wear safety eye, hand, leg, foot and body protection when operating this product.
Never handle or change head or line while engine is ON or in RUNNING position.
Never operate this or any power equipment under the influence of medication or alcoholic beverages or while around children.
Inspect area and remove foreign objects such as glass, cans, rocks, metals, wires, etc. prior to trimming.
Be alert to vibrations or damage to your trimmer head or gas powered equipment.
Turn engine OFF first, and then inspect for damage, replace parts when damage occurs.
When hard substances are encountered, stop operation, turn trimmer engine OFF, and inspect for damage.
We appreciate you as a Customer. Please exercise extreme care when handling or operating this or any other product.
Always Think Safety First.

KPI Kwik Products, Inc.

For assistance visit our web site: www.kwikproducts.com
OR

Call 1-888 CUT-KWIK
Mon-Fri 10AM-4PM EST.

KWIK LOADER KL450A ADAPTER APPLICATION GUIDE

JOHN DEERE
C1200

HOMELITE
ST145,ST145M,ST145,ST155/
ST175,ST175C/BC/G,ST385,ST485
SX135/C,EASY TRIM,20680,77
ZR SERIES TRIMMERS
HBC18,HBC28,BC300,HBC30B/I
HLT15,HLT16,HLT17C,HLT18
HLT28,PHANTON SS,HGT,GST,GST18
GSTBC,EZ REACH,EXPAND 3N1/+
ST185/BC/C,ST275,ST285,/BC,ST385
ST385BC/C/I,ST485,ST725/CDR,CEA
TRIM & EDGE/PLUS,TRIM LITE
VERSA TOOL/PLUS,BC730SBR
D630CD/D725CDE,D730CDV,D825CA
D825SB/SD/SBPLUS,D830CA/CBSBA
I625CD,I630CD,I725CC/CEA/CE
I730CC/CA,S825CDV/SEV,Z625CD/V
Z725CA/CD/CBV/CE/CEA/SE
Z825SB/A,Z830SB/SBA,EZ REACH

McCULLOCH
MAC60-SX,65/SL,MAC80SX/DX/SL
EAGER BEAVER EB280,EB285
EBISX,EB282,EB287,EB15RT
MAC15RT,MAC2815/2816/2817/2818
PM2025,2045,SILVER EAGLE 28/C
SE2SL,TITAN2010,2100,2200,2250
2030,ALL ROAD RUNNER MODELS
EAGER BEAVER SUPER/J PLUS
11SX,PROMAC1/SUPER,POWER PRO

LAWNBOY
1100,1150,1300,1330,1360,1400,1400CL
3100,3130,51620,51638,51903,51906
51911,51916,51920,51926,61620
61638,3160,SSIA,SSIB,

RYOBI
ALL CORDED ELECTRIC MODELS
500,700,700R,710,710R,720R,760R
764R,765R,766R,770R,920,960,970
705R,725R,767R,775R,975R,825R,
875R

IDC/RYAN: 120,130,260,262,263,264
264-1,264-2,264-3,265-1,265,P270
280,364,364-1,365

SEARS /CRAFTSMAN
74131,79605
*(SOME MODELS MAY REQUIRE
SPECIAL INSTALLATION INSTRUCTIONS)

TORO
51903,51904,51907,51906,51911
51912,51916,51917,51920,51921
51926,51927,51450,51620,51638

POULAN/WEEDEATER
GT115T-17C/XT,20T-40/HP,22-22T
*ALL CURED SHAFT UNITS
*ALL FEATHER- LITE UNITS
*(SEE SPECIAL INSTALLATION INSTRUCTIONS)

**NOTE: If Your Model Number Is Not Listed Above
Call Toll Free For More Information**

KPI Kwik Products, Inc.

Call 1-888 CUT-KWIK
Mon-Fri 10AM-4PM EST.
WEB: www.kwikproducts.com

**INSTALLATION FOR
John Deere, Homelite, Servistar
Toro, IDC/Ryan, McCulloch and
Lawnboy Trimmers**

Step #1: Loosen bump knob

Step #2: Remove bump knob, spool and spring

NOTE: DO NOT REMOVE TRIMMERS OUTER CUP

Step #3: Insert nylon spacer onto trimmer shaft first with solid side down

NOTE: (Homelite trimmers insert flat 3/8" silver washer before nylon spacer is installed) then followed by the Kwik Loader head. Place adapter through the center of head aligning the triangle key way of adapter with head. Insert the top half of the adapter aligning pins into the base. Then place the correct bolt into the hex recess. Screw down trimmer head by hand until tightened securely

NOTE: DO NOT OVER TIGHTEN!

**SPECIAL INSTALLATION FOR
Poulan/Weedeater & Some
Sears/ Craftsman Trimmers**

Step #1: Remove Original Trimmer Head From Trimmer

Step #2: Place the 3/8 triangular adapter into the center recess of the Kwik Loader head and align the triangle boss with triangle opening in recess.

Step #3: Place the small washer over the triangular adapter.

Step #4: Thread the selected 3/8 nut into the center of the Kwik Loader head and tighten securely

**INSTALLATION FOR
RYOBI SPEED SPOOL UNITS**

Step #1: Loosen bump Knob

Step #2: Remove bump knob, spool and "C" clip from shaft then remove plastic slider and spring.

NOTE: Pliers may be needed to remove "C" clip.

Step #3: Insert only the triangle half of the adapter through bottom of the Kwik Loader head aligning the triangle key way, then place the complete Kwik Loader head onto shaft. Insert correct size nut supplied into adapter hex housing. Grip Kwik Loader head and tighten securely by hand until trimmer head is seated properly on the base of existing cup.

NOTE: DO NOT OVER TIGHTEN!

NEED HELP!

Call 1-888-CUT-KWIK

Monday - Friday 10AM-4PM, EST.

OR

Visit our web site : www.kwikproducts.com

